

HOT WATER,

WHEREVER AND WHENEVER YOU NEED IT.



INSTALLATION **INSTALL IN 10 EASY STEPS**



BUILT FOR

DURABILITY



TOTAL PEACE OF MIND









2KW & 3KW POWER OUTPUTS AVAILABLE UNDERSINK & OVERSINK

DON'T FORGET ...

HOW EASY IS IT TO INSTALL?



Unpack appliance and read instructions



Check fittings are present



3.

Fit dielectric junctions



Mount the unit on the wall



5.

Connect cold pipework



6.

Connect hot pipework



Install discharge pipework and 6 BAR PRV



8.

Connect electrics



Turn on mains water



10.

Eniov your hot water



DON'T FORGET... INSTALLATION KITS A, B & C

DON'T HAVE THE REQUIRED PIPEWORK FOR EXPANSION? Use Kit A

Expansion Vessel and Non-return Valve



IS YOUR MAINS WATER PRESSURE OVER 3.5 BAR? Use Kit B

3.5 Bar Pressure Reducing Valve



NEED TO RUN YOUR DISCHARGE PIPE OUTSIDE? Use Kit C

Discharge Tundish









HOT WATER I HEATING I RENEWABLES ariston.co.uk



@AristonUK f /AristonUK / /AristonThermo







